
# **Setup Sheet for Program MAZE**

DOCUMENT PATH: C:\Users\Omar\Documents\MAZE Assignment\MAZE.SLDPRT



#### **Total**

NUMBER OF OPERATIONS: 7 NUMBER OF TOOLS: 7

Tools: T1 T2 T3 T4 T5 T7 T10

Maximum Z: 0.6in Minimum Z: -0.3in

MAXIMUM FEEDRATE: 68.7551in/min MAXIMUM SPINDLE SPEED: 10000rpm CUTTING DISTANCE: 742.221in RAPID DISTANCE: 101.544in ESTIMATED CYCLE TIME: 36m:37s

### **Tools**

# **T1** D1 L1

Type: spot drill

DIAMETER: 0.25in

MINIMUM Z: -0.2in

MAXIMUM FEED: 30in/min

TIP ANGLE: 90°

MAXIMUM SPINDLE SPEED: 1528rpm

LENGTH: 0.85in CUTTING DISTANCE: 0.8in

FLUTES: 3 RAPID DISTANCE: 11.6in

DESCRIPTION: 1/4" Spot Drill ESTIMATED CYCLE TIME: 2s (0.1%)

HOLDER: Maritool CAT40-ER32-2.35 COMMENT: Maritool CAT40-ER32-2.35

VENDOR: Maritool

PRODUCT: CAT40-ER32-2.35



# **T2** D2 L2

TYPE: spot drill MINIMUM Z: -0.15in

DIAMETER: 0.313in MAXIMUM FEED: 30in/min

TIP ANGLE: 90° MAXIMUM SPINDLE SPEED: 1222rpm

Length: 0.975in Cutting Distance: 0.2in

FLUTES: 3 RAPID DISTANCE: 1.3in

DESCRIPTION: 5/16" Spot Drill ESTIMATED CYCLE TIME: 0s (0%)

HOLDER: Maritool CAT40-ER32-2.35 COMMENT: Maritool CAT40-ER32-2.35

**VENDOR:** Maritool

PRODUCT: CAT40-ER32-2.35



T3 D3 L3

 Type: spot drill
 Minimum Z: -0.25in

 Diameter: 0.25in
 Maximum Feed: 30in/min

 Tip Angle: 90°
 Maximum Spindle Speed: 1528rpm

LENGTH: 0.85in CUTTING DISTANCE: 0.4in

FLUTES: 3 RAPID DISTANCE: 4.349in


DESCRIPTION: 1/4" Spot Drill ESTIMATED CYCLE TIME: 1s (0%)

HOLDER: Maritool CAT40-ER32-2.35

COMMENT: Maritool CAT40-ER32-2.35

**VENDOR:** Maritool

PRODUCT: CAT40-ER32-2.35



**T4** D4 L4

TYPE: spot drill MINIMUM Z: -0.3in

DIAMETER: 0.187in MAXIMUM FEED: 30in/min

TIP ANGLE: 90° MAXIMUM SPINDLE SPEED: 2037rpm


Length: 0.725in Cutting Distance: 0.2in Flutes: 3 Rapid Distance: 1.6in

DESCRIPTION: 3/16" Spot Drill ESTIMATED CYCLE TIME: 0s (0%)

HOLDER: Maritool CAT40-ER32-2.35 COMMENT: Maritool CAT40-ER32-2.35

**VENDOR:** Maritool

PRODUCT: CAT40-ER32-2.35



**T5** D5 L5

TYPE: flat end mill

DIAMETER: 0.25in

MAXIMUM FEED: 68.7551in/min

LENGTH: 0.85in

MAXIMUM SPINDLE SPEED: 4584rpm

FLUTES: 3

CUTTING DISTANCE: 146.612in

DESCRIPTION: 1/4" Flat Endmill RAPID DISTANCE: 30.485in

ESTIMATED CYCLE TIME: 2m:8s (5.8%)

HOLDER: Maritool CAT40-ER32-2.35

COMMENT: Maritool CAT40-ER32-2.35

**VENDOR:** Maritool

PRODUCT: CAT40-ER32-2.35



**T7** D7 L7

Type: flat end mill MINIMUM Z: -0.3in

DIAMETER: 0.125in MAXIMUM FEED: 27.502in/min
LENGTH: 0.6in MAXIMUM SPINDLE SPEED: 9167rpm
FLUTES: 3 CUTTING DISTANCE: 228.803in


DESCRIPTION: 1/8" Flat Endmill RAPID DISTANCE: 22.949in

ESTIMATED CYCLE TIME: 8m:19s (22.7%)

HOLDER: Maritool CAT40-ER32-2.35 COMMENT: Maritool CAT40-ER32-2.35

**VENDOR:** Maritool

PRODUCT: CAT40-ER32-2.35



**T10** D10 L10

Type: flat end mill MINIMUM Z: -0.3in
DIAMETER: 0.062in MAXIMUM FEED: 15in/min

LENGTH: 0.288in MAXIMUM SPINDLE SPEED: 10000rpm
FLUTES: 3 CUTTING DISTANCE: 365.206in

DESCRIPTION: 1/16" Flat Endmill RAPID DISTANCE: 29.261in

ESTIMATED CYCLE TIME: 24m:21s (66.5%)

HOLDER: Maritool CAT40-ER32-2.35 COMMENT: Maritool CAT40-ER32-2.35

VENDOR: Maritool

PRODUCT: CAT40-ER32-2.35



**Operations** 

Operation 1/7

DESCRIPTION: Drill3 MAXIMUM Z: 0.6in STRATEGY: Drilling MINIMUM Z: -0.2in

WCS: #0 MAXIMUM SPINDLE SPEED: 1528rpm
TOLERANCE: 0in MAXIMUM FEEDRATE: 30in/min
CUTTING DISTANCE: 0.8in


RAPID DISTANCE: 11.6in
ESTIMATED CYCLE TIME: 2s (0.1%)

COOLANT: Flood

**T1** D1 L1

Type: spot drill Diameter: 0.25in Tip Angle: 90° Length: 0.85in Flutes: 3

DESCRIPTION: 1/4" Spot Drill



Operation 2/7

DESCRIPTION: Drill4 STRATEGY: Drilling

WCS: #0 TOLERANCE: 0in MAXIMUM Z: 0.6in Мимим Z: -0.15in

MAXIMUM SPINDLE SPEED: 1222rpm MAXIMUM FEEDRATE: 30in/min

CUTTING DISTANCE: 0.2in RAPID DISTANCE: 1.3in

ESTIMATED CYCLE TIME: 0s (0%)

COOLANT: Flood

**T2** D2 L2

Type: spot drill DIAMETER: 0.313in TIP ANGLE: 90° LENGTH: 0.975in FLUTES: 3

DESCRIPTION: 5/16" Spot Drill

Operation 3/7

DESCRIPTION: Drill5 STRATEGY: Drilling

WCS: #0 TOLERANCE: 0in Maximum Z: 0.6in Мімімим Z: -0.25in

MAXIMUM SPINDLE SPEED: 1528rpm MAXIMUM FEEDRATE: 30in/min CUTTING DISTANCE: 0.4in RAPID DISTANCE: 4.349in

ESTIMATED CYCLE TIME: 1s (0%)

COOLANT: Flood

T3 D3 L3

Type: spot drill DIAMETER: 0.25in TIP ANGLE: 90° LENGTH: 0.85in FLUTES: 3

DESCRIPTION: 1/4" Spot Drill



Operation 4/7

DESCRIPTION: Drill6 STRATEGY: Drilling

WCS: #0 Tolerance: 0in MAXIMUM Z: 0.6in Мимим Z: -0.3in

MAXIMUM SPINDLE SPEED: 2037rpm MAXIMUM FEEDRATE: 30in/min CUTTING DISTANCE: 0.2in

RAPID DISTANCE: 1.6in ESTIMATED CYCLE TIME: 0S (0%)

COOLANT: Flood

**T4** D4 L4

Type: spot drill DIAMETER: 0.187in TIP ANGLE: 90° LENGTH: 0.725in

FLUTES: 3

DESCRIPTION: 3/16" Spot Drill



Operation 5/7

DESCRIPTION: Horizontal2 MAXIMUM Z: 0.6in Мимим Z: -0.3in STRATEGY: Horizontal

WCS: #0

MAXIMUM SPINDLE SPEED: 4584rpm TOLERANCE: 0.001in MAXIMUM FEEDRATE: 68.7551in/min STOCK TO LEAVE: 0in CUTTING DISTANCE: 146.612in MAXIMUM STEPOVER: 0.238in RAPID DISTANCE: 30.485in

ESTIMATED CYCLE TIME: 2m:8s (5.8%)

COOLANT: Flood

**T5** D5 L5

**T7** D7 L7 Type: flat end mill

DIAMETER: 0.125in

LENGTH: 0.6in

Type: flat end mill DIAMETER: 0.25in LENGTH: 0.85in FLUTES: 3

DESCRIPTION: 1/4" Flat Endmill



Operation 6/7

Description: Horizontal1 STRATEGY: Horizontal

WCS: #0 Tolerance: 0in STOCK TO LEAVE: ()in MAXIMUM Z: 0.6in Мимим Z: -0.3in

MAXIMUM SPINDLE SPEED: 9167rpm MAXIMUM FEEDRATE: 27.502in/min CUTTING DISTANCE: 228.803in MAXIMUM STEPOVER: 0.119in RAPID DISTANCE: 22.949in

ESTIMATED CYCLE TIME: 8m:19s (22.7%)

COOLANT: Flood

FLUTES: 3 DESCRIPTION: 1/8" Flat Endmill



Operation 7/7

DESCRIPTION: Horizontal3 STRATEGY: Horizontal

WCS: #0 TOLERANCE: 0in STOCK TO LEAVE: 0in MAXIMUM STEPOVER: 0.059in RAPID DISTANCE: 29.261in

MAXIMUM Z: 0.6in Мимим Z: -0.3in

MAXIMUM SPINDLE SPEED: 10000rpm MAXIMUM FEEDRATE: 15in/min CUTTING DISTANCE: 365.206in

ESTIMATED CYCLE TIME: 24m:21s (66.5%)

COOLANT: Flood

**T10** D10 L10

Type: flat end mill DIAMETER: 0.062in **LENGTH: 0.288in** FLUTES: 3

DESCRIPTION: 1/16" Flat Endmill



